


## NICE100+ Easy Setup Guide V0.0

**Safety Disclaimer:** Read and comply the safety instructions given in the NICE100+ User manual before performing any installation, operation and maintenance of the equipment. Must follow the NICE100+ user manual and NICE100+ Electrical Wiring Diagram for complete installation and commissioning of the NICE100+ Controller

**Aim:** This document is aimed & prepared to give basic commissioning and finetuning procedure for NICE100+ only




Product Technical Data					
Model	Input Current (A)	Output Current (A)	Motor Power (kW)	Braking Resistor ( $\Omega$ )	Braking Power (W)
3 $\phi$ , 380~480V (-15% to +10%)					
NICE-L-I-4003	10.5	9.0	3.7	170~135	$\geq 1100$
NICE-L-I-4005	14.8	13.0	5.5	115~90	$\geq 1600$


Product Dimensions						
Model	Horizontal Holes distance (A)	Vertical Holes distance (B)	Height (H)	Width (W)	Depth (D)	Bore Dia
NICE-L-I-4003	148mm	235mm	248mm	170mm	145mm	5.5mm
NICE-L-I-4005						

### Motor Tuning Procedure:


Motor Auto-tuning is required before start-up of the motor in any mode to obtained precise control parameters



## Inspection operation:



## Normal Operation:



- Maintain the default value for the above parameter for elevator speed upto 0.670m/s
- Call function terminals are connected at L1 ~L28 terminal of MCB to the field and are programmed in F6-11 to F6-38 parameters
- Input terminal functions (X1~X27) and output terminal functions (Y0~Y32) are programmed in F5-01~F5-27 and F7-00 to F7-32 parameters respectively
- For detailed terminal information and parameterization, please refer the NICE100+ user manual

**Caution:** Once again make sure that all safeties and its operating devices are functional before put the elevator in normal operation.

- Refer the up-terminal hoist-way switches installation and follow the same distance & position for bottom switches also
- All necessary field equipment installation and wiring must be done as per the standard needed for inspection operation
- Make sure that all elevator safeties are connected and functional, verify the function at X25, X26 & X27 of MCB
- Direction limit switches (X9 & X10) and terminal slowdown switches (X11 & X12) should be in operation
- Inspection command (X4) and directional inputs (X5 & X6) needed to be in proper function

### Set the following parameters

F0-04	Elevator Rated Speed	0.500m/s
F3-11	Elevator Inspection Speed	0.250m/s

- Now elevator can be run in Inspection mode from Cartop station or Cabinet station

- Commission the Elevator Door operation (Auto door /Manual door)
- Place the Floor Stopping/Door zone sensor and floor to floor slowdown sensor as per the requirement

Speed in m/s	0.670	1.000
Distance in mm	900~1000	1300~1500


### Set the following Parameter

F0-03	Elevator Normal Speed	0.480m/s
F6-00	No of Floor	5
F5-24	X24 Input for Floor slowdown	55

### Parameter setup for elevator rated speed of 1.000m/s

F3-02	Acceleration rate	0.500m/s <sup>2</sup>
F3-03	Acceleration jerk time 1	1.000s
F3-04	Acceleration jerk time 2	1.000s
F3-05	Deceleration rate	0.600m/s <sup>2</sup>
F3-06	Deceleration jerk time 1	1.000s
F3-07	Deceleration jerk time 2	1.000s

## Elevator Performance Adjustment Profile:



## Additional Performance Parameter List:

DC Injection Control Parameters			
F3-14	DC injection braking time at Start-up	0.000 ~ 1.000s	0.300s
F8-15	DC injection braking current at Start-up	0 ~ 150%	50%
F8-16	DC injection braking current at End	0 ~ 150%	30%
F8-11	DC injection braking time at End	0.000~1.500	0.300s
Brake Control Parameters			
F3-24	Brake Release Current threshold	0 ~ 100%	5%
F3-23	Brake Release speed threshold	0.000 ~ 0.100m/s	0.008m/s
F3-15	Brake Release Delay On set time	0.000 ~ 1.000s	0.050s
F3-25	Brake Apply Frequency threshold	0.000 ~ F3-10	0.005m/s
F3-16	Brake apply delay OFF set time	0.000 ~ 1.000s	0.200s
Special Control Parameters			
F2-11	Retard Coefficient	0~200	50%
F2-12	Retard Coefficient Enabling	0~1	0


## Fault History details:

NICE100+ is having more than 60 faults which starts from Err02 to Err63. Each fault is specifying the causes for the fault and remedy for the faults are listed in the NICE100+ user manual

E0-00 ~ E0-23	1 <sup>st</sup> Fault complete Record
E9-00 ~ E9-23	10 <sup>th</sup> Fault complete Record
FC-17 ~ FC-46	11 <sup>th</sup> to 20 <sup>th</sup> Fault type record

- NICE100+ can store up to 20 latest faults
- E0 ~ E9 stores the last 10 faults with complete details
- FC-17 ~ FC-46 stores another 10 fault types and time
- For more details, refer NICE100+ User manual

## Elevator Performance Fine-Tuning:



Stage	Symptom	Diagnostics	Remedies
<b>Start</b>	Rollback	Brake Releases too early	Increase F3-24
		Start Frequency is too low	Increase F3-00
	Starting Jerk	Torque Output is insufficient in VF mode	Make sure F2-43=0 for auto torque boost
		Brake Device releases too late	Decrease F3-24, F3-23, F3-15
<b>Acceleration</b>	Jerk when acceleration starts	Higher PI gains	Decrease F2-00 and increase F2-01
		Start frequency is high	Increase the F2-18 or Decrease F3-00
	Jerk when acceleration ends	Too fast acceleration	Decrease F3-02 or increase F3-03 or Decrease F2-00 & increase F2-01
		Overshoot at Acc. ends	Low PI gain
<b>Normal Speed</b>	Vibration	Improper PI gain	Adjust F2-00 and F2-03 relatively F2-01 and F2-04 also
		Improper current loop gain	Check the motor parameters and do the motor tuning again
<b>Deceleration</b>	Jerk when Dec. starts	Too fast deceleration	Decrease F3-05 or increase F3-06
	Vibration	Improper deceleration	Adjust F3-05 to F3-07
	Jerk when deceleration ends	Too fast deceleration	Decrease F3-05 or increase F3-07
	Undershoot at Dec. ends	Too small PI gain	Increase F2-03 & F2-00 and decrease F2-04 & F2-05 Increase F2-11 with F2-12=1
<b>Creeping Speed</b>	Vibration	Improper PI setting	Adjust F2-05 lower than the creep speed frequency
	Slower speed than set value	Too small PI	Increase F2-11 with F2-12=1 Adjust Slip gain F2-06 in SVC and F2-45 in VF mode
<b>Stopping</b>	Jerk	Too fast deceleration & high PI gain	1. Decrease F3-19 and increase F3-20 & F3-21 2. Decrease F2-00 and increase F2-01
		Brake apply too early	Adjust brake parameters F3-16, F3-25
		Too strong DC injection	Decrease DC injection at F8-16
	Slip	Inadequate DC injection at stop	Increase DC injection at F8-16
		Brake apply delay	Adjust brake parameters F3-16, F3-25
	Inaccurate Floor Level stopping	Parameter setting	Adjust floor levelling using Fr parameter and F4-00
Too low PI		Increase F2-00 & decrease F2-01 Increase F2-11 with F2-12=1	
Improper stopping deceleration		Adjust F3-19, F3-20, F3-21	
	Faster/slower creep speed	Adjust creep speed at F3-10	